



Blasting Machine-Tester Solus for 922/3000

NOT FOR USE IN GASSY COAL MINES

TECHNICAL DESCRIPTION

Blasting machine tester type SOLUS 922-F: Limit resistance 1260 Ohm for U (F)-detonators

Blasting machine tester type SOLUS 922-P: Limit resistance 50 Ohm for HU (P)-detonators

The testing instrument SOLUS 922-F is applicable for testing the electric capacity of the condenser discharge blasting machine type 922/3000 at 1260 Ohm fixed load resistor and indication of the glow lamp.

The testing instrument SOLUS 922-P is applicable for testing the electric capacity of the condenser discharge blasting machine type 922/3000 at 50 Ohm fixed load resistor and indication of the glow lamp.

The glow lamp lights if the capacity has reached the nominal value (100%) or more. When the capacity is reduced by more than 15% under the nominal value the glow lamp does not light anymore during the test. For the electric blasting only the first milliseconds after the activation of the ignition current (impulse) are necessary. Therefore in the testing instrument a comparator condenser (of blasting machine 922/3000) is charged, when the threshold voltage is reached a thyristor will be switched by means of a diode and the glow lamp lights.

Electric data (Testing of the indication):

The indication of the glow lamp lights when the energy content (power of the blasting machine) reaches at least 85% of the nominal value.

Charging voltage	= 2766 V (less voltage)	no function
Capacity of the firing condenser	= 40 μ F (normal capacity)	of the glow lamp
Charging voltage	= 3000 V (normal voltage)	no function
Capacity of the firing condenser	= 34 μ F (less capacity)	of the glow lamp
Charging voltage	= 3000 V (normal voltage)	function
Capacity of the firing condenser	= 40 μ F (normal capacity)	of the glow lamp

Construction:

The housing consists of three parts and is made of strong plastic. A 7 mm thick sight glass in the top of the housing enables an observation of the indicating glow tube. The three housing parts are connected by means of two screws. The type label is fixed on the side.

Measurement and weight:

Measurement:	Diameter	88 mm
	Height	92 mm
	Sight glass \varnothing	21 mm
Total weight:	0,80 kg	

Handling and testing:

The SOLUS tester is suitable for testing the capacity of the Schaffler blasting machines. The tester is adjusted to the blasting machine type and therefore for each blasting machine type the appropriate tester is required. As the blasting machines have to work under hard conditions without any complication it is necessary to test them periodically at least once a month. If the blasting machine was not in operation for a longer period (more than one month) it has to be tested with the Solus tester before operation. This test shows whether the blasting machine works absolutely reliable in mechanical and electrical field.

The tester SOLUS type 922-F or 922-P is connected to the blasting machine 922/3000. Now the blasting machine is operated in the same manner if detonators were connected to it. If the blasting machine has been correctly operated the indicating glow tube must distinctly light up. If the glow tube gives no response in spite of several operations of the blasting machine the latter is defective and should be taken out of operation, provided that the SOLUS tester is in perfect order, and should be sent to the manufacturer for verification and repair. The tester SOLUS does not need any maintenance at all apart from keeping it clean and protecting it from wetness.

When testing reliability, the blasting machine should also fulfil the following mechanical conditions:

- The connecting terminals must be able to be turned easily; their thread has to in order for the leading line to be steadily connected. The contact surface must be blank.
- The drive and the trigger should be operated easily.
- Machines with direct manual drive need a properly working free-wheel device.
- The housing must be checked for rough damages; this is of great importance for blasting machine types used in gassy coal mines.
- When shaking the blasting machine no noise from inside may occur.

The electric testing should include examination concerning short-circuit and electric capability. The attempt to test the blasting machine with a light bulb or a measuring instrument (voltmeter – amperemeter) does not bring any results apart from destroyed means of help. When some defect has been found out during electric and mechanical tests the blasting machine has to be returned to the manufacturer for repair and service. Repair works which make an opening of the blasting machine necessary must be done in the manufacturer's workshop as he has the essential means and knowledge.

All blasting machines and testing instruments have to be treated gently. They should not be stored in wet mine excavations and not under strong thermal fluctuations to avoid condensed water inside the instrument.

